

Rotary actuator for butterfly valves

- Nominal torque 90 Nm (not constant)
- Nominal voltage AC/DC 24 V
- Control Open-close
- Running time motor 35 s
- Optimum weather protection for use outdoors



Nominal voltage	AC/DC 24 V
	50/60 Hz
	AC 19.228.8 V / DC 21.628.8 V
	9 W
· · · · · · · · · · · · · · · · · · ·	2 W
Power consumption for wire sizing	12 VA
Connection supply / control	Cable 1 m, 3 x 0.75 mm ²
Parallel operation	No
Torque motor	Max. 90 Nm (not constant)
Manual override	Gear disengagement with push-button, can be
	locked
Running time motor	35 s / 90°
Sound power level motor	62 dB(A)
Position indication	Yes
Protection class IEC/EN	III Safety extra-low voltage
Protection class UL	UL Class 2 Supply
Degree of protection IEC/EN	IP66
Degree of protection NEMA/UL	NEMA 4, UL Enclosure Type 4
EMC	CE according to 2004/108/EC
Certification IEC/EN	IEC/EN 60730-1 and IEC/EN 60730-2-14
Certification UL	cULus according to UL 60730-1A, UL 60730-2- 14 and CAN/CSA E60730-1:02
Mode of operation	Type 1
Rated impulse voltage supply / control	0.8 kV
Control pollution degree	4
Ambient temperature	-3050°C
Ambient temperature note	-4050°C for actuator with integrated heating
Non-operating temperature	-4080°C
Ambient humidity	100% r.h.
Maintenance	Maintenance-free
Connection flange	F07
	Connection supply / control Parallel operation Torque motor Manual override Running time motor Sound power level motor Position indication Protection class IEC/EN Protection class UL Degree of protection IEC/EN Degree of protection NEMA/UL EMC Certification IEC/EN Certification UL Mode of operation Rated impulse voltage supply / control Control pollution degree Ambient temperature Ambient temperature Ambient humidity Maintenance

Safety notes



Weight

Weight approx.

 This device has been designed for use in stationary heating, ventilation and air conditioning systems and must not be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.

5.8 kg

- Only authorised specialists may carry out installation. All applicable legal or institutional installation regulations must be complied during installation.
- Junction boxes must at least correspond with enclosure IP degree of protection!
- The cover of the protective housing may be opened for adjustment and servicing.
 When it is closed afterwards, the housing must seal tight (see installation instructions).
- The switch for changing the direction of rotation may not be adjusted.
- The angle of rotation is not permitted to be subjected to mechanical limitation. It is forbidden to alter the mechanical end stops.



Safety notes

- The device may only be opened in the manufacturer's factory. It does not contain any parts that can be replaced or repaired by the user.
- The device contains electrical and electronic components and must not be disposed
 of as household refuse. All locally valid regulations and requirements must be
 observed.
- The actuator is not designed for applications where chemical influences (gases, fluids) are present or for utilisation in corrosive environments in general.
- The actuator may not be used in plenary applications (e.g. suspended ceilings or raised floors).
- The materials used may be subjected to external influences (temperature, pressure, construction fastening, effect of chemical substances, etc.), which cannot be simulated in laboratory tests or field trials. In case of doubt, we definitely recommend that you carry out a test. This information does not imply any legal entitlement.
 Belimo will not be held liable and will provide no warranty.
- If cables which are not authorised for UL (NEMA) Type 4 applications are guided out
 of the unit, then flexible metallic cable conduits or suitable threaded cable conduits
 of equal value are to be used.

Product features

Fields of application

The actuator is particularly suitable for utilisation in outdoor applications and is protected against the following weather conditions:

- UV radiation
- rain / snow
- dirt / dust
- Humidity
- Changing atmosphere / frequent and severe temperature fluctuations (recommendation: use the actuator with integrated factory-installed heating which can be ordered separately to prevent internal condensation)

Simple direct mounting

Simple direct mounting on the butterfly valve. The mounting orientation in relation to the butterfly valve can be selected in 90° (angle) increments.

Manual override

Manual override with push-button possible (the gear is disengaged for as long as the button is pressed or remains locked).

The housing cover must be removed for manual override.

High functional reliability

The actuator is overload protected, requires no limit switches and automatically stops when the end stop is reached.


Combination valve/actuator

For valves with the following mechanical specifications in accordance with ISO 5211 F07:

- Square stem head SW = 17 mm for form-fit coupling of the rotary actuator.
- Hole circle d = 70 mm

Torque not constant

Due to the non linear torque characteristic the actuator can only be used for butterfly valves and not for other armatures.





Accessories

Electrical accessories

Description	Туре
Auxiliary switch, add-on, 1 x SPDT	S1A
Auxiliary switch, add-on, 2 x SPDT	S2A
Feedback potentiometer 140 Ohm, add-on	P140A
Feedback potentiometer 200 Ohm, add-on	P200A
Feedback potentiometer 500 Ohm, add-on	P500A
Feedback potentiometer 1 kOhm, add-on	P1000A
Feedback potentiometer 2.8 kOhm, add-on	P2800A
Feedback potentiometer 5 kOhm, add-on	P5000A
Feedback potentiometer 10 kOhm, add-on	P10000A
Heating with mechanical humidistat HH24-MG	HH24-MG
Heating with adjustable thermostat HT24-MG	HT24-MG
·	· · · · · · · · · · · · · · · · · · ·

Electrical installation




Notes

- Connection via safety isolating transformer.
- Direction of rotation switch is covered. Factory setting: Direction of rotation Y2.

Wiring diagrams

AC/DC 24 V, open-close



Y2 A - AB = 0%


Cable colours:

- 1 = black
- 2 = red
- 3 = white



Dimensions [mm]

Dimensional drawings



Further documentation

- Overview Valve-actuator combinations
- Data sheets for butterfly valves
- Installation instructions for actuators and/or butterfly valves
- · General notes for project planning